


## TCC Accumulator Spring

**Part No.**  
**44912-01**

Springs (5)

### Chrysler 45RFE, 545RFE, 65RFE, 66RFE, 68RFE



#### 1. Disassembly

- Remove OE accumulator retainer, spring and valve.
- Discard spring, while keeping valve and retainer for reuse.
- Ensure all broken spring pieces are removed.

#### 2. Installation & Assembly

- Inspect valve and bore for wear or damage from broken spring.
- Insert Sonnax spring into valve and install into accumulator bore.
- Secure with OE valve retainer.